


# Floor to Ceiling Cable Display

USER INSTRUCTIONS



## Fitting Instructions

Make sure the fixings are strong enough to allow tensioning of the cables. Screws supplied are suitable for wooden ceilings for cavity and solid ceilings use the appropriate rawlplugs.

A) Fix fitting 1 to ceiling

B) Screw fitting 2 to fitting 1

C) Use a plumb line to mark the centre position of the floor fitting 5

D) Adjust the length of cable by loosening the grub screws at 4. cut off the cable in line with point A

E) Re tighten the grub screws 4

F) Adjust the tension by screwing 3 into 5. Do not over tighten

### Distance between cable centres

The distance between cables depends on the literature or poster holders you are adding. To calculate width required add 45mm to the width of the holder.

EG

A4 poster holder is 210mm wide + 45mm = 255mm

The cable centres need to be 255mm apart


A4 cable centres 255mm apart

A3 cable centres 342mm apart

A2 cable centres 465mm apart

A1 cable centres 639mm apart

A0 cable centres 886mm apart



0844 800 1020

c a b l e **DISPLAYS**

sales@discountdisplays.co.uk

31-35 Wortley Road, Croydon, Surrey, CR0 3EB • Fax 020 8665 5606